



# RZR Front Tow Hook Installation Instructions

## Tools Required

15mm wrench

Razor Blade

17mm wrench

T40 Torx

Step 1: Remove or loosen the torx bolts holding the front fascia on the RZR. Test fit the tow hook to see if you need to trim the plastic. Sometimes you can just loosen the plastic to install the tow hook.



Step 2: Insert the (4) M10 bolts from the outside through the tow hook and frame. Put the (4) washers and nylock nuts on the back side of the frame. Tighten the hardware.



Step 3: Here you can see where the plastic normally is indicated by the green lines. The red line indicates the area that you may need to trim with a razor blade for the plastic fascia to clear the bolt heads. The plastic indicated by the green lines was completely removed to better show the tow hook and is not necessary for the installation. Reinstall the front fascia if removed.



Step 4 (Optional): If you are using the tow hook as a tie down point and use straps with large hooks, you may need to change the center two bolts. You can use (2) 3/8-16 x 1" grade 8 bolts with washers. It should provide just enough clearance.

