



RZR Milwaukee Packout Mount Install Instructions

Tools Required

7/16 socket or wrench

9/16 socket or wrench

7/32 Allen wrench

Step 1: Attach the side brackets to the main base with the (4) ¼-20 carriage bolts and nylock nuts. The bolts should be adjusted in the middle of the slots for most applications. The brackets are side specific (passenger side shown in first photo).

Step 2: Place the mount in the forward position of the bed. Hold one backing plate against the bed plastic under the fender. Align the vertical slots of the bed plastic with the backing plate. Thread two of the knobs into the backing plate from the inside of the bed.

Step 3: Insert one 3/8 button head bolt through the middle slot of the bed plastic from the inside. Install the nut on the backing plate from under the fender with the 9/16 socket or wrench. The bolt only needs to be tight enough to hold the backing plate in position when you remove the main mounting plate for cleaning or engine access. Repeat on the other side.

Step 4: Ensure all 4 knobs are tight but NOT HULK TIGHT!!! Install your Milwaukee Packout Tool Boxes or Cooler and get to riding. To clean the bed or access the engine you only need to remove the 4 knobs to remove the mount. Do not remove the middle button head bolt and backing plate.

