



Rock Ready UTV

RZR Packout Single Mount

Tools Required

T40 torx driver

10mm socket and ratchet

Step 1. Using the T40 torx, remove the (2) outside, rear torx screws from the bed floor. Make sure the plastic washers are also removed if present. Replace with the (2) provided aluminum spacers.



Step 3. Install the mount utilizing the (2) flange head bolts with a 10mm socket and ratchet. The mount is reversible so that the toolboxes or cooler can be inserted and opened left or right handed.

